



BLAZER LEP, LED, &
Infrared Illuminators
Light Shaping Diffusers
Clamp & Retaining Ring
Tools & ORING Tethers



Zip Bag Contents

- 1 pc Hot Spot & Spill (installed)
- 3 pc Beam Diffusers (see list)
- 1 pc Diffuser Retaining Ring
- 1 pc Clamping Ring
- 1 pc Retaining Ring Tool
- 1 pc Hex Key Tool
- 6 pc O-Ring Tethers



CLAMP
TOOL



CLAMP

40° FLOOD
WHITE

DIFFUSER
ASSEMBLY



15° FLOOD
YELLOW

GREEN



RETAINING
RING TOOL



6X
ORING
TETHERS

**Green Diffuser Works On
White Lights ONLY -
Not Infrared Illuminators**

- Diffusers - 4x INCLUDED
- 1 pc Flood 15°
 - 1 pc Flood, CQB 40°
 - 1 pc Hot Spot & Spill
 - 1 pc Green - Predator Hunt

Installation Steps

1. The clamping & retaining rings have struts that must be aligned for o-ring attachment.
2. Make sure the bolt head (for hex key tightening) is on the right side, or left if you're a lefty.
3. Once aligned, connect the retaining ring and the clamping ring struts with the supplied o-ring tethers. (one, or two each side)
4. Now that both the clamping & retaining rings are tethered, back out the clamping ring bolt.
5. Slide the entire assembly over the light head.
6. Once the o-ring tethers are moderately taught, tighten the bolt to secure the clamping ring.
7. The assembly should be thumb "flippable" with relative ease - fine adjustments may be needed to dial in your preferred diffuser position.
8. Use the "half moon" retaining ring tool to switch out one of the 4x included beam diffusers - 15° & 40° Flood; Hot Spot & Spill; Green.
9. Diffusers have protective film covers to prevent damage. 15° = Yellow, 40° = White; Green = Clear.